COVERAGE **DOWN THE ROAD**

Royal Protect is a fully insured product backed by more than 25 years of dependability. Whether you need repairs to your car as a result of a mechanical breakdown, roadside assistance or have general guestions regarding your coverage, we're there with the expertise to resolve any issues quickly. All Royal claims associates are experts in the field and have decades of experience in automotive claims and repair. With our state-of-the-art call center and our national coverage, immediate response to your needs are met.

New Vehicle Protection Lease Vehicle Protection Pre-Owned Vehicle Protection Substitute Transportation 24-Hour Roadside Assistance **Trip Interruption Intervention** 100% Backed 25 Years of Dependable National Coverage

Facts SERVICE every automobile owner should know:

- The average person drives 15,000 miles per year, dropping most owners out of factory warranty within 2.5 years.
- The average buyer will own a new vehicle for 7 years exposing the owner to significant repair costs for 4.5 years.

Now you can get extended protection for your new or pre-owned vehicle. Royal Protect Vehicle Protection is the choice for coverage, flexibility, and value with a selection of program levels designed to fit any vehicle or budget.

OPTIONAL COVERAGE

- Technology Group: The following Manufacturer-Installed components are covered: DVD Players; Radio; CD Players; Video and Gaming Systems; Navigation Systems, Back-up Camera, Parking Sensors.
- Seals and Gaskets: Seals and gaskets will be covered only if the Seals and Gaskets option is selected at the time of purchase and the appropriate surcharge is paid Note: Seepage of seals and gaskets is considered normal wear and tear and is not covered under this Service Contract.

SURCHARGES

- Commercial Use Coverage (This Coverage is ONLY available on the Ultimate Coverage Plan, with the Term Expiration). Commercial Use is defined as any vehicle used as a necessary part of, or in conjunction with, Your employment. Commuting and car/van pools are not considered commercial use. **Any Vehicle which has any of the following features is not eligible for Commercial Use Coverage: Diesel, Turbo/Supercharger, Four-Wheel Steering, 4X4, AWD, and a snow plow or power take-off (whether equipped at time of Contract purchase or at a later date).
- 4 Wheel/All-Wheel Drive Coverage: If Your Vehicle is equipped with 4 Wheel/All-Wheel Drive, the following components are covered regardless of the Plan You purchased: 4 Wheel Drive Actuator and Locking Hubs
- Diesel: If You have a diesel Vehicle, an additional mandatory surcharge is applied.
- 1 Ton Vehicle: If You have a vehicle with a one ton gross vehicle weight capability, (GVW) an additional mandatory surcharge is applied.
- Turbocharger/Supercharger (factory installed only): All internal components contained within the Turbocharger/Supercharger Housing, Turbo Boost Valve, Turbo Waste Gate Actuator, Bearing, Bushing, and all other internal components, and Seals and Gaskets, Supply Line.
- Hybrid/Electric Vehicle: Electric Motor, Power Controller, Inverter Assembly, Generator, Drive Motor Temperature Sensor/Switch, Battery Cooling Fan Relay/Module, Damper, Electric Water Pump, Electric Air Conditioning Compressor and Battery Cooling Fan, Water Assembly Valve. A mandatory surcharge is applied if Your Vehicle is a hybrid or fully electric model.

Customer Service	800.871.0467
Claims	800.871.0467

Royal Protect Vehicle Protection is backed by an insurance company that is rated A by A.M. Best



Royal Administration Services, Inc. 51 MIII Street, Building F Hanover, MA 02339 PH 800.871.0467 FAX 781.261.2522 www.rovaladmin.com Florida License # 60109 The provider of the service contract in AK, AZ, CA, LA, NV, WA and WI is United Service Protection Corp. In Florida, the Provider is



RPBR Rev 2.16

United Service Protection Inc, FL License #60016 PO Box 20647, St. Petersburg, FL. 33742, 1-800-283-0785 In OK, the provider is Assurant Service Protection Inc,

This brochure is not a contract. Be sure to read a contract for coverage information, including limitations, exclusions and terms and conditions. Certain Conditions and components are excluded, such as inadequate maintenance of the vehicle, corrosion, and parts designed for limited life such as bulbs, filters and brake pads. See the exclusion section of the service contract for complete details

RUH OTE R



PRIMARY

Drive Chain

Manual and

Automatic

covered if

internally

and Tourque

Seals

PRIMARY ENGINE • The following are covered if damage is caused by the mechanical failure of an internally lubricated part: Cylinder Block Cylinder Head(s) All Internal components of • Transfer Case the engine block and cylinder head(s) Camshaft Bearings Bushings Crankshaft • Oil Pump Pistons • Output Shaft Bearings • Main Shaft PRIMARY All Internal **AUTOMATIC OR**

Coverage includes:

STANDARD TRANSMISSION **AND TRANSFER** CASE Internal Components of the Transmission or Manual Transmission

within the Transfer Case DIFFERENTIAL ASSEMBLY (FRONT AND REAR) Differential Housing



• Axle Shaft • Drive Chain Gears . Ring and Pinion • Carrier Bearings Bearings . Internal Transaxle . Bushinas Washers Differential Cover All internal parts Transmission Case contained within the differential Converter are assembly damaged by an PRIMARY **DRIVE AXLE** lubricated part (FRONT AND REAR) • Drive Axle Planetary Gears Shift Rail Fork Constant Velocity Joint Center Support Bearing • Drive Shaft Universal Joints **PRIMARY SEALS** Lubricated parts AND GASKETS • All Seals and Gaskets are covered provided that they're

required in

repair of a

covered part

connection with a

PREFERRED

Includes all	PREFERRED	 Reverse Light
components	AUTOMATIC OR	Switches
covered	STANDARD	
under Primary	TRANSMISSION	PREFERRED All
PLUS:	AND TRANSFER	CONDITIONER
	CASE:	 Condensor
PREFERRED	 Flywheel 	 Compressor
ENGINE	Flex Plate	
		Compressor
Cylinder Block	Electronic Shift	Pressure Relie
 Cylinder Head(s) 	Control Unit	Valve
all internal parts	 Transmission 	 Compressor
contained within	Cooler	Clutch and Pu
the engine block	 Transmission 	• Air
 Pistons 	Mounts	Conditioning
 Piston Rings 	 Oil Pan 	Lines and Hose
 Connecting Rod 	 Shift Linkage 	 Evaporator
Bearings	 Shift Bushings 	 Idler Pully and
 Crankshaft 	• Manual	Idler Pully
Crankshaft Main	Transmission Case	Bearing
Bearings	Automatic	 High/Low
	Transmission Case	
Camshaft Camshaft		Compressor
Camshaft	• Transmission	Cut-Off Switch
Bearings	Cooler Lines	 Expansion Val
 Cam Followers 		 Pressure Cyclir
 Timing 	PREFERRED	Switch
Chain/Belt	STEERING	 Accumulator/
 Timing Gears 	 Steering Box 	Receiver Dryer
Guides	 Steering Rack 	 Orifice Tube
 Tensioners 	 Power Steering 	 Coverage
Rocker Arms	Pump	applies to
Rocker Shafts	All components	factory installe
Rocker Bushings	contained therein,	units only
		units only
Cylinder Head	if damaged by the	
Valves	failure of an	PREFERRED
 Valve Guides 	internally	BRAKES
 Valve Lifters 	lubricated part	 Master Cylinde
 Valve Springs 		 Vacuum/
 Valve Seals 	PREFERRED	Hydraulic
 Valve Retainers 	ELECTRICAL	Booster
 Valve Seats 	 Ignition Switch 	 Disc Brake
 Push Rods 	Lock Cylinder	Calipers
Water Pump	Starter Solenoid	 Wheel Cylinde
Oil Pump	Alternator	 Compensation
Oil Pump	Starter Motor	Valve
Uning		
Housing	Voltage Regulator	 Brake Hydraul
Harmonic	• Starter Drive	Lines and
Balancer	• Engine	Fittings
Oil Pan	Compartment	 Hydraulic
 Timing Chain 	Wiring Harness	Control Unit
Cover	 Ignition Switch 	 Wheel Speed
 Intake and 	 Electronic Ignition 	Sensors
Exhaust	Module	 Hyrdaulic
Manifolds	 Front and Rear 	Pump/Motor
Valve Covers	Window Wiper	Pressure
Engine Mounts	Motor	Modulator
Wrist Pins		Valve/Isolation
	Headlamp Switch	
Connecting Rod	Washer Pump and	Dump Valve
Distributor Drive	Switch	Accumulator
Gear	 Stop Lamp Switch 	Electronic
 Dip Stick Tube 	 Turn Signal Switch 	Control
 Balance Shaft 	 Blower Speed 	Processor
 Balance Shaft 	Switch	
Bearing	 Horns 	PREFERRED
 Balance Shaft 	 Neutral Safety 	SEALS AND
Bushing	Switch	GASKETS
Valve Locks	Power Window	Head Gaskets
Oil Pump Pickup	Switch	and Intake
	Power Door Lock	Gaskets
Engine Cooler	Switch	Gaskets
	JWITCH	

e Light Components es covered under Primarv and **RED AIR** Preferred PLUS: IONER nsor **PREMIUM FRONT** essor **AND REAR** ressor SUSPENSION ure Relief Control Arms ressor Control Arm and Pully Shafts and tioning Bearing and Hoses Torsion Bars rator Mounts and Pully and Bushings ully Ball Joints ow Strut Bearing ressor Plates ff Switch Radius Arms and ision Valve Bushinas are Cycling Stabilizer Bar Stabilizer nulator/ /er Dryer Link/Bushings e Tube Spindle and ade Spindle Support es to Wheel Bearings v installed only THE FOLLOWING PARTS OF THE RED VARIABLE DAMPENING r Cylinder COVERED ulic Compressor rake Control Module Dampening Cylinders Actuator ensation Solenoid • Strut Height Hydraulic Sensor and Mode Selector Switch ulic ol Unit PREMIUM Speed STEERING ulic Steering Box 'Motor Power Steering re Pump lator Power Steering lsolation/ Hoses Valve nulator • Pitman Arm onic Idler Arm Drag Link sor Steering Dampeners RED AND **IS**

PREMIUM

 Internal Tilt Switch Cooling Fan Wheel Mechanism Motor Stepper Motors • Fuel Gauge Control Valves Oxygen Sensor Mass Air Flow Rear Wheel Steering Sensor • Throttle Position Rear Steering • Upper and Lower Shaft and Sensor EVP Sensor Couplings Power Cylinder Knock Sensor and Pump Cooling Sensor Electronic Control Crank/Cam Sensor Unit/Solenoid Ambient Temp • Phase Control Sensor Unit Control Valves **PREMIUM FUEL** • Upper and Lower DELIVERY Rack • Tie Rod Ends • Fuel Pump Fuel Injection PREMIUM Pump and **ELECTRICAL** Injectors Automatic Vacuum Pump Climate Control • Fuel Tank Programmer • Fuel Tank Rear Defogger Sending Unit Metal Fuel Switch Power Door Lock **Delivery Lines** Actuator and Pressure Switch Regulator and Electrical Idle Air Control Instrument Motor Cluster SUSPENSION ARE Mileage PREMIUM COOLING Computer Distributor Cooling Fan and Motor Ignition Coil • Fan Clutch Powertrain Control Module Belt Tensioner Radiator Cruise Control Module Heater Core Cruise Control Thermostat Engagement Blower Motor Switch • Hot Water Valve Headlamp Motor Overflow Power Window Reservoir Motors Radiator Cap Thermostat Power Window Regulators Housing Power Seat Low Engine Coolant Module Motor Power Mirror PREMIUM SEALS Steering Knuckles Motor Power Antenna & GASKETS Motor/Mast All Seals and Gaskets are Assembly Convertible Top covered on all Motor components Sun Roof Motor • Upper and Lower listed under Steering Column Power Seat Primary, Shaft and Switch Preferred and Coupling Power Mirror Premium

RPBR Rev 2.16

ULTIMATE

Covers all vehicle parts except:

- Anti-theft system
- Any equipment when not installed by the Vehicle
- Manufactuer
- Batterv
- Brake Lining and Brake Pads
- Catalytic Converter
- Coolant Hoses and Drive Belts
- Drums and Rotors Except When Damaged By a Covered Part
- Exhaust System
- Glass and any treatments or chemicals related to any glass
- Lenses
- Light Bulbs
- Television
- Tires/Wheels/

Wheel Covers • Trim

- Upholstery/ Convertible & Vinyl Tops
- Manual Transmission Clutch components
- Moldings/ Weather-Strips
- Paint
- Passive or active saftey and restraint systems, and any sensors and/or components related to those systems
- Radio/speaker equipment
- Recreational Vehicle equipment
- Remote Controls, Key Fobs or Keyless
- components
- Sealed Beams

- Sheet
- Metal/Bumpers Shocks and
- Struts Spark Plugs and Wires
- Suspension Air Bags
- Telephone, Satellite Service or Systems
- Video Entertainment and/or Gaming Systems
- Wiper Blades
- The components described in the Vehicle's Manufactures Maintenance Schedule when such components are repaired or replaced as part of routine or manufactures recommended maintenance

